



INSTALLATION INSTRUCTIONS

Large ID Replacement Fuel Rails

2005 – 2010 4.6l Ford Mustang

Part No. PF-3012



PF-3012 Contents

<u>Description</u>	<u>Qty.</u>
Fuel Rail	2
Fuel Rail to Manifold Bracket	4
Screw & Lock Washer ¼-20	4

The fuel rails contained in this kit replace the factory production fuel rails intended for use in a customized fuel system. This kit does not include a provision for attachment of the OEM production fuel pressure sensor directly to the fuel rail. Performance Fuel Systems, Inc. kit PF-3016 has a provision to directly attach the OEM production fuel pressure sensor to the fuel rail.

Caution:

Installation of this product involves handling of gasoline and should be conducted in a well ventilated area with fire safety equipment readily available. Work area should be free of open flames and other sources of ignition. Smoking in the work area is prohibited. Wear eye goggles and other appropriate safety apparel to protect from sprayed gasoline and other debris.

It is recommended that the installation be conducted by a qualified automotive technician with knowledge of automotive fuel systems and repair procedures.

This kit is not legal for sale or use on emission controlled motor vehicles in certain states. Check with local authorities for the specific regulations in your local area.

Installation Instructions:

Warning:

Fuel rail and fuel lines may be under high pressure. Fuel system pressure must be properly relieved before opening system. Refer to vehicle manufacturer's service manual for proper fuel system bleed down procedures. Failure to properly relieve fuel system pressure may result in a fire or personal injury.

The enclosed fuel rail kit is intended to be installed on an unmodified production OEM intake manifold. Performance Fuel Systems, Inc. cannot guarantee fitment on an aftermarket intake manifold or modified production intake manifold and is not responsible for verifying proper fitment.

Removal of Production OEM Fuel Rail Assembly:

1. Disconnect battery negative cable. Relieve fuel system pressure per vehicle manufacturer's service manual.
2. Disconnect electrical connectors from each fuel injector. Note the location of each connector.
3. Clean any dirt or debris at the base of each fuel injector.
4. Place a shop towel underneath the fuel supply feed line quick connector at the fuel rail, disconnect the supply feed line from the fuel rail. A quick connect disconnect tool is required for the removal of the feed line from the quick connector. Use the shop towel to catch any fuel spillage.
5. Disconnect any vacuum lines or electrical wiring that may interfere with the removal of the fuel rails.
6. Remove the 4 bolts holding the fuel rail to the intake manifold.
7. Remove the fuel rail with injectors by gently pulling up on the fuel rail assembly. Do not separate the fuel injectors from the fuel rail while removing from the intake manifold.
8. Using a shop towel beneath the fuel rail assembly, remove the injector retaining clip holding the fuel injector to the fuel rail and gently pull the injector out of the fuel rail port. There may be a considerable amount of fuel remaining in the fuel rail which will drain upon removal of the fuel injectors. Use a drain cup or shop towel to catch any gasoline that may leak out from the fuel rail.

Note: Failure to properly follow safe handling procedures can result in fire or personal injury.

Assembly and Installation:

1. Install supplied mounting bracket and 1/4-20 screw with lock washer to the logo side of the Performance Fuel Systems, Inc. fuel rail. Install so that the bracket with the slotted hole is facing upwards and the bracket top surface is parallel with the fuel rail. **See Figure 1.** Tighten bracket into position onto fuel rail. Repeat for remaining three brackets.
2. Install desired end fittings into the fuel rail ends (not included). Fuel rail ports are machined for industry standard ORB (O-ring Boss) fittings with thread size of 7/8-14. The ends are made to seal with the appropriate o-ring sealed fitting. Do not use thread sealant on the mating male fittings when installing into fuel rail ends.



Figure 1

3. Remove, inspect and clean both o-rings from the fuel injectors. It is recommended to replace the o-rings prior to re-installation. O-rings are available at your vehicle's manufacturer service center or auto parts store.
4. Install the o-rings onto the fuel injectors carefully as to not cut or damage the o-ring.

5. Lightly oil upper fuel injector o-rings and insert fuel injectors into the Performance Fuel Systems, Inc. fuel rail ports being careful not to cut or damage the o-rings. The OEM production injector retaining clips are not required.

6. Position fuel injectors so that the wire connector terminals are pointing in the opposite direction of the mounting brackets. **See Figure 2.**

7. Lightly oil the bottom fuel injector o-rings and install the fuel rail – injector assembly by lining up and inserting the fuel injectors into the intake manifold ports making sure the top end of the injectors do not dislodge from the fuel rail.

Important: Position the fuel rails into the intake manifold so that the brackets are facing inward and the fuel injector wiring connectors are facing outboard.



Figure 2

8. Insert the fuel rail assembly so that the injectors bottom out in their intake manifold ports. Make sure that the fuel injector o-rings are fully seated in the intake ports as well as the fuel rails ports. For both ends of the fuel injector, the o-rings should be seated so that neither are exposed. Check to make sure the fuel rail bracket mounting slots are aligned with the intake manifold mounting screw holes.

9. Inspect and clean the production fuel rail to intake manifold attachment screws. Replace if necessary. Align and install screws through the slotted fuel rail brackets and thread into the intake manifold. Tighten and torque screws per vehicle manufacturer's recommended specification.

10. Check proper alignment of fuel injectors. Fuel injectors should be perpendicular to the fuel rail and sitting straight in the intake ports. If alignment is not correct, loosen and adjust mounting brackets to the intake manifold and/or recheck the position of the brackets to the fuel rail.

11. The fuel rails are now ready to be connected to your customized fuel system. It is the end users responsibility to complete the connections to the fuel rails using appropriate fuel lines and fittings.

12. Reinstall vacuum hoses and electrical wiring.

13. Reinstall fuel injector wire connectors to their corresponding fuel injector.

14. Reconnect negative battery cable. Turn ignition on to pressurize the fuel system but do not start the engine. Check fuel pressure (if available) and look for leaks. If leaks are found, shut-off ignition and repair leaks.

15. If no leaks are found, start engine and check again for leaks. If any leaks are found, immediately shutoff engine and repair leaks.

16. If no leaks are found, you have successfully installed your Performance Fuel Systems, Inc. fuel rail kit.

Performance
Fuel Systems, Inc.

P.O. Box 1221, Toy, MI 48099

(248) 914-8732

E-mail: sales@performancefuelsystems.com

Website: performancefuelsystems.com

LIMITED WARRANTY

This Performance Fuel Systems, Inc. product is warranted to be free from defects in materials and workmanship for a period of one year from the original date of purchase. Warranty claims must include authentic, dated proof of purchase.

All claims must be made by the original retail purchaser directly to Performance Fuel Systems, Inc. by calling 248-914-8732 or by e-mail sales@performancefuelsystems.com in order to review proof of purchase and to receive a Returned Material Authorization (RMA) number and return shipping instructions. All returns are to include the RMA number and are to be shipped pre-paid freight by the retail purchaser. All returned product will be inspected for improper installation, modifications and misapplication. If the product is determined to be defective, the retail purchaser will be refunded the value of the sale price and will not include costs associated to direct, incidental or consequential damages. This Limited Warranty covers only the product itself and not the cost of installation or removal.

Performance Fuel Systems, Inc. expressly retains the right to make changes and improvements at any time in any product the company manufactures and sells. Changes and improvements may be made without notice and without any obligation to change published materials.

This Limited Warranty is in lieu of and excludes all other warranties, expressed or implied. This Limited Warranty gives you specific legal rights. Other rights may be applicable which vary from state to state.



P.O. Box 1221, Toy, MI 48099
(248) 914-8732

E-mail: sales@performancefuelsystems.com

Website: performancefuelsystems.com